


# **BRIFIELD BR3 BODY CAMERA USER MANUAL**



**Customer service email address  
[info@brifield.co.uk](mailto:info@brifield.co.uk)**

# CONTENTS

**Page 1** - BR3 Diagram







**Page 2 / 3 / 4** - BR3 Diagram  
explanation

**Page 5** - Screen functions / Menu  
explantaion

**Page 6 / 7 / 8** - Menu explanation

**Page 9 / 10 / 11 / 12** - Important  
information

**Page 12** - Important Information /  
Product box contents / Customer  
service



# BR3 DIAGRAM EXPLANATION

**1 - Right LED light:** **A.** Flat **GREEN** when idle. **B.** Flashing **RED** when recording a video. **C.** Temporary flat **RED** when a picture is taken in idle mode. **D.** Flashing **AMBER** light when recording an audio recording. **E.** Flat **GREEN** when the USB lead is connected to a computer.

**2 - Left LED light:** **A.** Flat **WHITE** when device is fully charged. **B.** Flat **BLUE** when charging and when the USB lead is connected to a computer.

**3 - Sensor:** Detects low and high light levels, this is what triggers the automatic IR night vision.

**4 - Infrared night vision lights:** Gives a white vision that helps in very low light areas, or nighttime.

**5 - White LED light:** Helps in low light areas.

**6 - Lens:** Capture Video and images. The lens is also what triggers the motion detection.

**7 - USB port:** Connect the BR3 USB cable to your computer, from there you can transfer your recorded video, audio files and pictures to the

computer. **Reset hole:** Next to the USB port. This is used to reset the device.

**8 - Picture button:** **A.** In idle mode, press to take a picture. **B.** While recording a video, press to take a picture.

**9 - Audio record button:** **A.** In idle mode, press to start an audio recording. **B.** In idle mode and also while recording, hold for 2 seconds to switch between 720p and 1080p video resolutions.

**10 - 2 Inch LCD screen.**

**11 - Left button:** **A.** In idle mode, press to play the last recorded video, audio or picture. **B.** In playback mode, press to rewind the video. **C.** In menu mode, press to scroll up. **D.** In playback mode, hold to zoom out the picture.

**12 - Middle button:** **A.** In idle mode, press to access the playback mode. **B.** When recording a video or audio recording, press once to activate the **Important file button**. This will add a STAR icon on the video or audio file in playback mode. This will also add a S letter at the end of the file name on your computer. This helps to easily identify the more important video and audio files.

**C.** In playback mode, press to play and pause the recording. **D.** In menu mode, press to select.


**13 - Right button:** **A.** In idle mode, press to enter menu mode. **B.** In menu mode, press to scroll down. **C.** In playback mode, press to fast forward the video. **D.** In playback mode, hold to zoom in the picture.

**14 - Video record button:** **A.** In idle mode, press once to start a video recording. **B.** When the device is switched off, hold for 3 seconds to power on the device, and start a video recording immediately. **C.** While recording, hold for 2 seconds to lock the record button and the power on/off button. Hold the record button again for 2 seconds to unlock these 2 buttons.

**15 - IR Light / White LED light button:** **A.** In both idle mode and while video recording, press to turn on/off the IR night vision lights. **B.** In both idle mode and while recording a video, hold for 2 seconds to turn on/off the white LED light.

**16 - Power button:** **A.** Hold for 3 seconds to switch the device on/off. **B.** Press to go back or exit. **C.** Press once to turn the LCD screen on/off.

# SCREEN FUNCTIONS



# MENU EXPLANATION

Use left button number 11 to go up. Right button number 13 to go down. Middle button number 12 to select. Button number 16 to go back.

- **Video Resolutions:** Change the video resolutions.
- **Picture Megapixel:** Change the Megapixel of the camera.
- **Burst:** These are different picture burst options. Let's say you select 5 bursts, now when you take a picture, 5 pictures will be taken one after the other.
- **Self timer:** This gives you a countdown, when the countdown reaches 0 then a picture will be taken.

- **Continuous shooting:** When on, pressing the picture button will activate continuous shots every 5 or 10 seconds depending on what you have selected in the menu. To stop the continuous shots, press the picture button once again.
- **Quality:** The quality of the video recordings.
- **Pre-record:** This feature will pre-record a short clip before you press the record button, it will then integrate itself into the main recording.
- **Delay record:** The amount of time the device waits until it stops the video recording.
- **Loop record:** When the memory card becomes full, the loop feature will automatically override the earliest recording then continue to record over the following recorded videos.
- **Split time:** This is how long you want the video clips to be.
- **Slide show:** This allows a slideshow within the internal picture playback mode. Changes picture every 5 seconds.
- **Infrared:** Manual Mode lets you turn the IR on and off yourself manually, and auto mode activates the IR automatically when the view in front of the lens is dark and deactivates when the view is light.
- **Motion Detection:** Turn on/off. You will know the motion detection is activated because there will now be a face icon on the LCD screen. Once the motion detection is turned on from within the menu,

press the record button. Now any motion in front of the lens will trigger the device to start a video recording. The device will continue to record, but when there is no longer any motion in front of the lens, there is a 10 second countdown. After the 10 seconds, the video will stop recording.

- **Record warning:** When turned on, the device voice says "Recording started." When deactivated, there is no voice.

- **Record mute:** When activated, this will mute the video recording.

- **Language:** Select your language.

- **Screen save:** The amount of time the screen will stay on until the LCD screen turns off.

- **LCD Brightness:** Option of Low / High.

- **Auto Power off:** The amount of time the device will remain idle before powering off.

- **LED light:** Option to turn the 2 LED lights at the top of the BR3 permanently off.

- **Key tone:** Turn the key tone on/off.

- **Volume:** Change the volume of camera speaker. This affects the loudness of video playback, audio playback, the key tone, record warning, and any other sounds played by camera. This does not affect the volume of the recorded video or audio files themselves.

- **Coding format:** Select whether you would like to use H.264 or H.265 coding.

- **ID Setting:** Change the user ID. Use the left and right keys to change the letter or number and use the middle key to select and move onto the next character.
- **Change password:** Use the left and right buttons to change character and use the middle button to select and move onto the next character.
- **Time setup:** Adjust the time and date.
- **Default setting:** This will reset the internal settings back to the default settings.
- **Version of the device:** The version of the current device.
- **Date/Time stamp:** Select whether you want to remove the date and time stamp from the playback or keep them there.

# IMPORTANT INFORMATION

**Memory Card (MAC users only):** The only way to completely delete your recorded files and free up your memory from your BR3 body camera, is to empty your trash bin on your MAC. If you don't do this, then eventually the memory card will become full, and when it's full you won't be able to record any new footage.

**How to use the Klickfast chest harness:** First you need to slot the Klickfast stud piece into the back of the body camera. Then you slot that piece into the Klickfast chest harness. You will hear a click; this is now locked in place. The only way you can unlock is to turn the body camera 180 degrees or upside down, then pull up and out.

**Transfer files to PC:** Plug the USB lead into the computer. Enter the password. Find the drive file on the computer. Once you are in the file, click onto the DCIM file. From there you can access all the recorded files. Drag the files from the DCIM files to your computer.

**Key lock the record button:** When you hold down the record button for 2 seconds, this will lock the record button and also lock the power on/off

button. To unlock it, hold down the record button for 2 seconds.

**H.264 and H.265 video coding:** H.265 coding uses half the memory and gives a better quality video picture. But it uses more battery power than H.264. If you want more information on H.265 there are many articles online, alternatively email us at [info@brifield.co.uk](mailto:info@brifield.co.uk)

**Change password:** Access the change password within the menu, enter your old password (Left key to go up, and right key to go down, middle key to select and move on to the next one. **(The default password is 000000)** Now enter the new password. Then enter your new password again to confirm it. If you have forgotten your custom made password then call or email us and we will take care of this for you.

**Change user ID:** Select ID setting from the menu. Use left key to go up, use right key to go down, use middle key to select and move on to the next character.

**Reset device:** To reset the device, use a small tool to jab the reset button. You will know the camera has been reset because you will hear a faint click sound. If the camera is turned on while you reset it, the camera will turn off, this is another way of knowing that you have reset the camera. The reset

button is located next to the USB port under the flap.

**Computer playback app:** There are many different video playback apps online, some are free. You will need to download one to playback the video and audio files from this device. Or your computer might already have one pre-installed.

**Delete files:** You can only delete the recorded files from a computer. This is to stop people from getting rid of the evidence straight from the device itself. To delete the files from your computer, right click, then delete them.

**64GB Memory card:** There is a 64GB memory card built into the device, however the internal settings take up some memory space. The actual amount of memory you will get after the internal settings is normally around 57.9GB.

**Product warranty:** We offer a 12-month warranty on the Brifield BR3 body camera. This warranty covers faults that was caused by the manufacturer. If the fault was caused by the customer, then the warranty will be void.

**BR3 USB Lead:** Please only use the USB lead provided in the product box. Using other USB leads might cause damage to the BR3 body camera.

**IP65 Water rating:** Please note that the BR3 body camera is not fully waterproof. Do not submerge it into water. IP65 is the rating of the BR3 body camera, this is resistant to weather and dust. Rain will not damage the BR3.

## **PRODUCT BOX CONTENTS**

- 1 X BR3 BODY CAMERA**
- 1 X USB LEAD**
- 1 X UK 3 PIN PLUG**
- 1 X KLICKFAST CHEST HARNESS**
- 1 X KLICKFAST STUD**

## **CUSTOMER SERVICE**

If you have any questions at all then please feel free to email us or call us. We will do our absolute best to help you with all your questions and any technical problems.

**Email address: [info@brifield.co.uk](mailto:info@brifield.co.uk)**

**BRIFIELD  
BR3 BODY CAMERA  
USER MANUAL**



**Customer service email address  
[info@brifield.co.uk](mailto:info@brifield.co.uk)**